

Base Cabinet Assembly – Pocket Screws

Please see the wall cabinet instructions first. Base cabinets are assembled in a similar way as wall cabinets. See additional images and notes for base cabinet assembly below.

We recommend sliding the I-beams into the grooves before putting the back on. Wait to screw them in place until the back is attached to the sides. For the drawer boxes make sure they click into place and if you need to take them off press the blue/purple trigger release and they'll slide right off the guides.

If you have any questions about assembly, contact us at 800-506-7374.

Assembly Steps



