## **Corner Block Staple Assembly**

Using corner blocks is often more convenient than regular staples without corner blocks.

Use  $\frac{1}{2}$  wide x  $\frac{1}{2}$  deep 18 gauge staples for this application.

If you have any questions about this assembly type, contact us at 800-506-7374.



