

Assembly Instructions for Frameless Wall Cabinet



Assembly Tools:

- Brad Nailer
- Brad Nails 1-1/8" Minimum Length
- Carpenter Glue
- Screw Driver

Assembly Steps:

1) Begin by opening the box and laying all the pieces out on a clean, flat surface. Check to make sure all contents are in the box (hinges and shelf pins will be packaged separately in its

own plastic bags).

2) Wood glue is to be used on each dowel and dado.

3) Lay part A on its side with dado and predrill holes facing up.

4) Attach part E and G by inserting dowels into the predrilled holes on part A. Make sure the dowels are push in all the way. Dado on all parts should be facing inward and aligned with each other.

5) Slide part B (finish side inward) into the dado.

6) Attach part C to the opposite side of Part E and G.

Important: Use the brad nails to secure the cabinet box together.

7) Attach the hinge to the door (Part D).

8) Aligned the door to the desired position on the box and use the screws provided to secure the hinge to the box.

9) Position the shelf pins to the desired height and place shelf (Part F) on top of the shelf pins.

10) Final door adjustment can be made by adjusting the positioning screws on the hinge.