

## Wall Cabinet Assembly – Pocket Screws

Start out with the frame face down and add glue in all the grooves. Then align the sides and screw them down using the pocket holes. Be careful not to overdrive the screws.

Add glue in the grooves on the sides and insert the top/bottom. Then install the back panel. We recommend using clamps for easier back panel installation.

If you have any questions about assembly, contact us at 800-506-7374.

### Assembly Steps





