


# Assembly Instructions


W0930, W0936  
 W1230, W1236  
 W1530, W1536  
 W1830, W1836  
 W2130, W2136  
 WBLC30/33-3030L/R,  
 WBLC39/42-3630L,  
 WBLC30/33-3036L/R,  
 WBLC39/42-3636L

W2430B, W2436B,  
 W2730B, W2736B,  
 W3030B, W3036B,  
 W3330B, W3336B,  
 W3630B, W3636B  
 W4230B, W4236B  
 W4830-2D24


A-Door&Faceframe(1)    B-Side Panel(2)    D-Top&Bottom(2)    E-Back Panel(1)    F-Shelf(2)  
 I-Hardware Box(1):                      Shelf Clip-(8)                       $\phi 3.5*30(6)$




(1)







(2)



(3)



METAL CLIP  
 INSTALLATION



(4)

# Assembly Instructions

W2442B W2742B W3042B

## PARTS:

- A - Front Panel -2pc
- B - Side Panel -2pc
- C - Top & Bottom Panel - 2pc
- D - Back Panel - 1pc
- a - Shelves - 3pc

## HARDWARE BAG(H)

- \*Shelves support - 12pcs
- \*Plastic lid - 4pcs
- \*4 × 14 Screws - 12pcs
- \*3.5 × 25 Screws -4pcs

Before you start, please prepare a soft surface on the floor before you take out all the wooden components. Now take them out with care and put them on the soft surface to avoid scratching the wooden parts.

